



Aft end of retainer.  
Align with aft end  
of flight pack

Drill Thru 1/8" or  
3.2mm 6 places

# QRBT-RV8-KIT

## RETAINER DRILL TEMPLATE

160.5

Cut on dotted line all round

78.0

123.0

58.0

58.0